


REMINGTON®

ELECTRIC CHAIN SAW




**Models:
EL-4**

SPARE PARTS

CHAIN SAW

Model: EL-4



Key no.	Part no.	Description	Key no.	Part no.	Description
1	S/R	Decal Nameplate	20	4113.263	Bearing Roller Sprocket
2	4113.316	Housing Motor	21	4113.265	Gear Sprocket
3	4113.318	Disc Thrust	22	4113.277	Support Sprocket
4	4113.338	Bearing Roller	23	4113.208	Cover Side Black
5	4113.352	Field 230V, 1450W	26	4113.253	Screw Pph B 8-18X0.88
6	4113.249	Ball Steel	27	4113.353	Ring E
8	4113.351	Armature 230V	28	4113.255	Gear Drive 11T 200P
9	4113.302	Screw Flat Hd Tpg, 6-20X1.50	29	4113.301	Screw Pph Tpg 10-16X1.88
10	4113.282	Assembly Chain Brake	30	4113.261	Switch Lock-Off
13	4113.322	Bolt Hex Hd. 0.250-20X1.50	31	4113.267	Srew
14	4113.324	Housing Gear Black	32	4113.259	Clamp Cord
15	4113.223	Assembly Cap And Bulb	33	4113.096	Cord Molded
16	4113.209	Reservoir Oil	34	4113.257	Capacitor Suppression
17	4113.275	Plate Assy Adjusting	55	4113.207	Cover Sprocket
18	4113.007	Screw Tap Flat Hd. Pr	not shown	4113.320	Bar Giude 14" Symm.
19	4113.340	Nut Hex 0.250-20	not shown	4113.158	Chain Saw

S/R = Parts available by special request only

When ordering parts, be sure to provide the correct model, Desa part number and description.